



Originalfernbedienung Ersatzfernbedienung

	POWER		Power
	SCREEN SIZE		3D
	AUTO SET UP		Options
	MUTE		Mute
	ZOOM		Eject
	PC 1		Shift + 1
	PC 2		Shift + 2
	DISPLAY		Info
	TV		TV/R
	SCART		AV
	DVI		Shift + 3
	PLASMA MENU		D. Menu
	PLASMA MENU		Shift + D. Menu
	UP / CH +		Up
	UP / CH +		Ch +
	DOWN / CH -		Down
	DOWN / CH -		Ch -

Originalfernbedienung Ersatzfernbedienung

	RIGHT		Right
	LEFT		Left
	SET		Ok
	VOL +		Vol +
	VOL -		Vol -
	MENU TV		Menu
	PIP ON / OFF TV		Media
	PIP SWAP TV		I<<
	PIP MOVE TV		>>I
	PIP TYPE TV		Shift + Media
	AUDIO TV		Dual
	CLOCK TV		Sleep
	1 TV		1
	2 TV		2
	3 TV		3
	4 TV		4
	5 TV		5



