


















Originalfernbedienung Ersatzfernbedienung

	Power		Power
	TV/SAT		AV
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Smart
	FAV		Shift + Pre Ch
	Menu		Menu
	EPG		Guide

Originalfernbedienung Ersatzfernbedienung

	Recall		Pre Ch
	Exit		Exit
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	CH/Page+		Ch +
	CH/Page-		Ch -
	Red		Red
	TTX		Text
	Green		Green
	SUB.T		Subt
	Yellow		Yellow
	Zoom		Eject





Originalfernbedienung Ersatzfernbedienung

	Blue		Blue
	MP		3D
	Tv/Radio		TV/R
	Audio		Dual
	Pause		Pause
	Rec		Rec
	Info		Info
	P/N		Shift + Media
	POS		Media
	T/S		Options
	<<		<<
	>>		>>
	Play		Play
	Stop		Stop

Originalfernbedienung Ersatzfernbedienung

