













































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Stop		Stop
	TV/TXT		Text
	Cancel		Eject
	Reveal		D. Menu
	Hold		Media
	Size		3D
	Subpage		Shift + Subt
	Index		List
	Red		Red
	Green		Green

Originalfernbedienung Ersatzfernbedienung

	Yellow		Yellow
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Source		AV
	Vol+		Vol +
	Vol-		Vol -
	Menu		Menu
	Rec		Rec
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	DVB		Smart
	Exit		Exit
	1		1



