



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Eject/Open-Close		Eject
	DVD		Blue
	VCR		Yellow
	AV/Input		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	I.Skip		Guide
	Dubbing		Media

Originalfernbedienung Ersatzfernbedienung

	<</Backward		<<
	>>/Forward		>>
	I<< Skip		I<<
	Skip >>I		>>I
	Pause/Step		Pause
	Play		Play
	Stop		Stop
	Disc Menu/List		Menu
	Home		Smart
	Display		Info
	Return		Back
	PR/CH(TRK)+		Ch +
	PR/CH(TRK)-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left



