







































































Originalfernbedienung    Ersatzfernbedienung

	Red / -1		Red
	Green / +1		Green
	Yellow / Stop		Yellow
	Blue / [= ?]		Blue
	[=] / [TV]		Text
	1		1
	I << Video		I <<
	2		2
	>> I Video		>> I
	3		3
	Tint-		Media
	Tint+		Smart
	4		4
	5		5
	6		6
	Contrast-		Left
	Rec Video		Rec

Originalfernbedienung    Ersatzfernbedienung

	Contrast+		Right
	Stop Video		Stop
	7		7
	<< Video		<<
	8		8
	>> Video		>>
	9		9
	*-		Down
	Pause Video		Pause
	*+		Up
	Play Video		Play
	0 / AV		0
	Up / P+		Ch +
	i		Info
	P / C		Back
	Left / Vol-		Vol -
	OK		Ok



