







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Sleep		Sleep
	Internet Radio		Shift + 1
	Online Music		Shift + 2
	Music Server		Shift + 3
	Optical		Shift + 4
	Coaxial		Shift + 5
	Analog		Shift + 6
	Bluetooth		Shift + 7
	iPod/USB		Shift + 8
	I<<		I<<
	Play		Play
	Pause		Pause
	>>I		>>I
	CH+		Ch +
	CH-		Ch -
	ADD Favorites		3D



























Originalfernbedienung Ersatzfernbedienung

	CALL Favorites		Pre Ch
	Tone		Smart
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Top Menu		Menu
	Info		Info
	Search		TV/R
	Setup		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	1		1
	2		2
	3		3





Originalfernbedienung Ersatzfernbedienung

	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Guide
	Clear		Exit
	Random		Media
	Repeat		Text
	Mode		Format
	Dimmer		Subt

Originalfernbedienung Ersatzfernbedienung