





































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu		Menu
	OK/List		Ok
	Guide		Guide
	Media		Media
	Left		Left
	Right		Right

Originalfernbedienung Ersatzfernbedienung

	Down		Down
	Up		Up
	Exit		Exit
	Last		Back
	Info		Info
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Play		Play
	Stop		Stop
	Pause		Pause









Originalfernbedienung Ersatzfernbedienung

	Rec		Rec
	<<		<<
	>>		>>
	Sleep		Sleep
	Source		AV
	Wide		Format
	V-Format	 + 	Shift + Format
	OPT+		Options
	Edit		Eject
	Teletext		Text
	Tv/Radio		TV/R
	[...]		Subt
	[+=]		D. Menu
	?		Smart
	I>	 + 	Shift + Pause
	I<<		I<<
	[≡ ≡]		List






Originalfernbedienung Ersatzfernbedienung

	Audio		Dual
	>>I		>>I











Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	7		7
	8		8
	9		9
	0		0
	Menu		Menu
	<<		<<
	>>		>>
	Guide		Guide
	OK/List		Ok
	Up		Up
	Down		Down

Originalfernbedienung Ersatzfernbedienung

	Right		Right
	Left		Left
	Exit		Exit
	Info		Info
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -

