





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Eject/Open/Close		Eject / Surround
	DVD		Shift + 2
	VCR		Shift + 4
	AV/Input		AV / Input / RDS
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	I.Skip		Text / Goto
	Dubbing		Blue / Prime Video / Random

Originalfernbedienung Ersatzfernbedienung

	Power Tv		Shift + Power
	AV Input Tv		Shift + AV / Input / RDS
	PR+ Tv		CH+ / Page+
	PR- Tv		CH- / Page-
	Vol+ Tv		Vol+
	Vol- Tv		Vol-
	<<		<< / Tune-
	>>		>> / Tune+
	I<<<		I<<< / Preset-
	>>>I		>>>I / Preset+
	Pause/step		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	Home		Menu / Home
	Disc Menu/List		D.Menu / Top
	Disc Menu/List		Smart / List
	Up/PR/TRK+		Up



