



Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------|---|-------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | PgUp |  | Ch + |
|  | PgDn |  | Ch - |
|  | FAV+ |  | >>I |
|  | FAV- |  | I<< |
|  | Up/CH+ |  | Up |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|----------|---|--------|
|  | Down/CH- |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Menu |  | Menu |
|  | Exit |  | Exit |
|  | Red |  | Red |
|  | Green |  | Green |
|  | Yellow |  | Yellow |
|  | Blue |  | Blue |
|  | EPG |  | Guide |
|  | Audio |  | Dual |
|  | SUB |  | Subt |
|  | Zoom |  | Eject |
|  | FAV |  | Pre Ch |





| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | | Ersatzfernbedienung | |
|---|----------|---|-------|-----------------------|--|---------------------|--|
|  | List |  | List | | | | |
|  | Pause |  | Pause | | | | |
|  | TXT |  | Text | | | | |
|  | Info |  | Info | | | | |
|  | Tv/Radio |  | TV/R | | | | |
|  | Recall |  | Back | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

