



































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
POWER		Power	
EXIT		Exit	
MENU		Menu	
AUDIO		Dual	
VIDEO		Media	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
EPG		Guide	
FAV		Pre Ch	
OK		Ok	
∧		Up	
∨		Down	
<		Left	
>		Right	
VOL +		Vol +	
VOL -		Vol -	
CH -		Ch -	
CH +		Ch +	
MUTE		Mute	
TXT		Text	
TV/RADIO		TV/R	
ASPECT		Format	
RED		Red	
GREEN		Green	
YELLOW		Yellow	
BLUE		Blue	



