








































**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	Sleep		Sleep
	Display		Info
	Tape >		Right
	< Tape		Left
	<< Tape		Down
	>> Tape		Up
	Stop Tape		Ok
	Random		Media
	Clear		Exit
	P.Mode		Format
	Edit		Back
	1		1
	2		2
	3		3
	4		4
	5		5

**Originalfernbedienung    Ersatzfernbedienung**

	6		6
	7		7
	8		8
	9		9
	0		0
	+10/PTY Search		Guide
	O.T.E.		Pre Ch
	>>I P.Call		>>I
	I<< P.Call		I<<
	Stop CD		Stop
	Play CD		Play
	Pause CD		Pause
	Play MD		Shift + Play
	Pause MD		Shift + Pause
	Stop MD		Shift + Stop
	Tuner/Band		TV/R
	PTY		Options



