







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	ATV		Setup / OPT /
	DTV		D.Menu / Top
	3D		Display / Media
	HDMI		Shift + 0
	Input		AV / Input / RDS
	Sound		Sound / Title
	Picture		Picture / Format
	Zoom		Zoom / Size
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8

Originalfernbedienung Ersatzfernbedienung

	9		9
	Inf/Me		Info / Angle
	0		0
	Rec/Del		Back / Return
	Freeze		Shift + Pause / Step /
	EPG		Guide / EPG / -/-
	MTS		Text / Goto
	Mute		Mute / Dimmer
	Vol+		Vol+
	Prog+		CH+ / Page+
	Vol-		Vol-
	Prog-		CH- / Page-
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Menu		Menu / Home



