






































































**Originalfernbedienung Ersatzfernbedienung**

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	↔		Pre Ch
	Back		Back
	Menu		Menu
	Netflix		Media
	Internet		Smart
	Ok		Ok

**Originalfernbedienung Ersatzfernbedienung**

	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Mute		Mute
	i		Info
	Exit		Exit
	Source		AV
	Q.Menu		D. Menu
	EPG		Guide
	TXT		Text
	*		Format
	*/Q		3D



