






**Originalfernbedienung Ersatzfernbedienung**

	Power DVD		Power
	Display		Info
	SYS Video		Back
	On/Off PBC		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Guide
	Title		Pre Ch
	Repeat		Text

**Originalfernbedienung Ersatzfernbedienung**

	A-B/Repeat		Options
	Clear		Exit
	FTS/Program		Sleep
	Menu System		Menu
	Menu Disc		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Stop/Return		Stop
	Play		Play
	Pause		Pause
	>>		>>
	<<		<<
	>		>>
	<		<<



