





























Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Vol+		Vol +
	Vol-		Vol -
	Phono		1
	AUX1		2
	AUX 2		3
	Tape 1		4
	Tape 2		5
	Video 1		6
	Video 2		7
	Video 3		8
	Off		Exit
	A Tun		Ok
	Tuning >		Right
	< Tuning		Left
	CTR ECS		List
	< SRND Mode		Ch -

Originalfernbedienung Ersatzfernbedienung

	SRND Mode >		Ch +
	BAL CHK		Dual
	Delay Time >		Up
	< Delay Time		Down
	Pause Tape		Pause
	Play Tape		Play
	Stop Tape		Stop
	>> Tape		>>
	Rec/Zone		Options
	<< Tape		<<
	Band		Smart
	Rec Tape		Rec
	On Screen		Info
	Tuner		Media



