







































































Original	Replacement	Original	Replacement
 Power	 Power	 Favorite	 Shift + Pre Ch
 Mute	 Mute	 Play	 Play
 Subtitle	 Subt	 Pause	 Pause
 <<	 <<	 Stop	 Stop
 >>	 >>	 Info	 Info
 I<<	 I<<	 1	 1
 >>I	 >>I	 2	 2
 Record	 Rec	 3	 3
 Up	 Up	 4	 4
 CH+	 Ch +	 5	 5
 CH-	 Ch -	 6	 6
 Down	 Down	 7	 7
 Right	 Right	 8	 8
 Vol+	 Vol +	 9	 9
 Vol-	 Vol -	 0	 0
 Left	 Left	 EPG	 Guide
 OK	 Ok	 Tv/Radio	 TV/R





Original		Replacement		Original		Replacement	
	Audio		Dual				
	Recall		Pre Ch				
	Repeat	 + 	Shift + Text				
	Teletext		Text				
	File		Smart				
	Device		AV				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Menu		Menu				
	Exit		Exit				

