







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol-		Vol-
	Lang		Sound / Title		OK		OK
	Lang		Shift + Audio / Lang I/II		Right		Right
	Search		Red / Netflix / Search		Vol+		Vol+
	Memory		D.Menu / Top		Down		Down
	Favorite PR		Fav / Marker / PC		CH-		CH- / Page-
	Game		Picture / Format		Mute		Mute / Dimmer
	Teletext		Text / Goto		Audio		Audio / Lang I/II
	Guide		Shift + Guide / EPG / -/--		1		1
	PR List		Smart / List		2		2
	EPG		Guide / EPG / -/--		3		3
	Info		Info / Angle		Pause		Pause / Step / Freeze
	Menu		Menu / Home		4		4
	Exit		Exit / Cancel / Clear		5		5
	Up		Up		6		6
	CH+		CH+ / Page+		Tv/Radio		TV/Radio /
	Left		Left		7		7





	Original	Replacement		Original	Replacement
	8	8			
	9	9			
	Sleep	Sleep / Timer			
	0	0			
	P/N	Setup / OPT /			
	Recall	Back / Return			
	TV/AV	AV / Input / RDS			
	-	I<< / Preset-			
	+	>>I / Preset+			
	-/--	+ Shift + 0			
	Mode	Display / Media			

	Original	Replacement

