











Original	Replacement	Original	Replacement
	Power		Disc 1
	Sleep		FM Mode/Mute
	Cancel		L Balance
	Repeat		Balance R
	Play Mode		Tape Direction
	1		Tape Display
	2		SEA Mode
	3		S.A.Bass
	4		Surround Mode
	5		Rec Pause
	6		Fade Muting
	7		Vol+
	8		Vol-
	9		Up/PTY Search
	10		Play
	Disc 3		Down/RDS Display Mode
	Disc 2		Stop
	Power		Red
	Sleep		Menu
	Shift + Back		Text
	Shift + Text		AV
	Format		Exit
	1		Back
	2		Subt
	3		Options
	4		Dual
	5		Rec
	6		Mute
	7		Vol +
	8		Vol -
	9		Up
	10		Play
	Yellow		Down
	Green		Stop









































































Original	Replacement	Original	Replacement
 Right/PTY Select+	 Right		
 >> >>	 >>		
 Left/PTY Select-	 Left		
  << <<	 <<		















Original	Replacement	Original	Replacement
 Power	 Power	  <</>>	 <<
 Sleep	 Sleep	 Rec Pause	 Rec
 1	 1	 S.A. Bass	 Options
 2	 2	 Surround Mode	 Dual
 3	 3	 Up/PTY Search	 Up
 4	 4	 Down/PTY Display Mode	 Down
 5	 5	 Right/PTY Select+	 Right
 6	 6	 Left/PTY Select-	 Left
 7	 7	 Vol-	 Vol -
 8	 8	 Vol+	 Vol +
 9	 9	 FM Mode/Mute	 Menu
 10	 0	 Tape Direction	 Exit
 +10	 GUIDE	 Tape Display	 Back
 Play	 Play	 L Balance	 Text
 Stop	 Stop	 Balance R	 AV
 Fade Muting	 Mute	 Play Mode	 Format
 >> >>	 >>	 Repeat	 Shift + Text







































Original	Replacement	Original	Replacement
	Cancel		Shift + Back
	SEA Mode		Subt
	Disc 1		Red
	Disc 2		Green
	Disc 3		Yellow





Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 6	 6
 5	 5
 7	 7
 8	 8
 9	 9
 10	 0
 +10	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Play	 Play
 Fade Muting	 Mute
 Stop	 Stop

Original	Replacement
 Surround Mode	 Dual
 S.A.Bass	 Options
 SEA Mode	 Subt
 Up/PTY Search	 Up
 Down/RDS Display Mode	 Down
 Right/PTY Select+	 Right
 left/PTY Select-	 Left
 Sleep	 Sleep
 FM Mode/Mute	 Menu
 Tape Direction	 Exit
 Tape Display	 Back
 L Balance	 Text
 Balance R	 AV
 Play Mode	 Format
 Repeat	 Shift + Text
 Cancel	 Shift + Back
 Disc 1	 Red







































	Original	Replacement		Original	Replacement
		Disc 2		Green	
		Disc 3		Yellow	













Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 10	 0
 +10	 Guide
 Sleep	 Sleep
 Fade Muting	 Mute
 Play	 Play
 Stop	 Stop
 S.A. Bass	 Options

Original	Replacement
 Surround Mode	 Dual
 Vol+	 Vol +
 Vol-	 Vol -
 Up/PTY Search	 Up
 Down/RDS Display Mode	 Down
 Right/PTY Select+	 Right
 Left/PTY Select-	 Left
 >> >>	 >>
  <</<<	 <<
 FM Mode/Mute	 Menu
 Tape Direction	 Exit
 Tape Display	 Back
 L Balance	 Text
 Balance R	 AV
 Play Mode	 Format
 Repeat	 Shift + Text
 Cancel	 Shift + Back





	Original	Replacement	Original	Replacement
	SEA Mode			Subt
	Disc 1			Red
	Disc 2			Green
	Disc 3			Yellow

