






















Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue/Timer	 Blue / Prime Video / Random
 Format	 Picture / Format
 Res.	 D.Menu / Top
 TTX	 Text / Goto
 S-T	 Sound / Title
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold

Original	Replacement
 Rec	 Rec / Rec Mode
 PVR List	 Smart / List
 Menu	 Menu / Home
 Up	 Up
 Exit	 Exit / Cancel / Clear
 Left	 Left
 OK	 OK
 Right	 Right
 EPG	 Guide / EPG / -/--
 Down	 Down
 Info	 Info / Angle
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 Tv/Rad	 TV/Radio /
 Vol+	 Vol+
 Vol-	 Vol-
 Audio	 Audio / Lang I/II



