




















































Original	Replacement
AVR Power On	 Power
Mute	 Mute / Dimmer
Play	 Play / Slow
Pause	 Pause / Step / Freeze
Stop	 Stop / Hold
<<	 << / Tune-
>>	 >> / Tune+
I<<	 I<< / Preset-
>>I	 >>I / Preset+
Audio Effects	 Audio / Lang I/II
Surround Modes	 Eject / Surround
Video Modes	 Picture / Format
Sleep	 Sleep / Timer
Menu	 Menu / Home
Up	 Up
Info	 Info / Angle
Left	 Left

Original	Replacement
OK	 OK
Right	 Right
Back/Exit	 Exit / Cancel / Clear
Down	 Down
Last	 Back / Return
Vol+	 Vol+
AVR	 Smart / List
CH/Page Up	 CH+ / Page+
Vol-	 Vol-
CH/Page Down	 CH- / Page-
1	 1
2	 2
3	 3
4	 4
5	 5
6	 6
7	 7






















Original	Replacement	Replacement
1	 1	1
DVR	 Display / Media	
DVR Power On	 Power	
2	 2	2
3	 3	3
4	 4	4
5	 5	5
6	 6	6
7	 7	7
8	 8	8
9	 9	9
0	 0	0
Menu	 Menu / Home	
Up	 Up	
Down	 Down	
Right	 Right	
Left	 Left	

Original	Replacement	Replacement
Mute	 Mute / Dimmer	
Vol+	 Vol+	
Vol-	 Vol-	
CH/Page Up	 CH+ / Page+	
CH/Page Down	 CH- / Page-	





Original	Replacement
Bluray Power	 Power
Mute	 Mute / Dimmer
Play	 Play / Slow
Pause	 Pause / Step / Freeze
Stop	 Stop / Hold
Rec	 Rec / Rec Mode
<<	 << / Tune-
>>	 >> / Tune+
I<<	 I<< / Preset-
>>I	 >>I / Preset+
Disc Menu	 D.Menu / Top
Menu	 Menu / Home
Up	 Up
Left	 Left
OK	 OK
Right	 Right
Back/Exit	 Exit / Cancel / Clear

Original	Replacement
Down	 Down
Last	 Back / Return
Vol+	 Vol+
Vol-	 Vol-
Blu-ray	 Display / Media
1	 1
2	 2
3	 3
4	 4
5	 5
6	 6
7	 7
8	 8
9	 9
0	 0
Red	 Red / Netflix / Search
Green	 Green / APP / Repeat





Original	Replacement
AVR Power On	Power
AVR Power Off	Shift + Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Menu	Menu / Home
Back/Exit	Exit / Cancel / Clear
Last	Back / Return
Up	Up
Down	Down

Original	Replacement
Right	Right
Left	Left
OK	OK
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Vol+	Vol+
Vol-	Vol-
Mute	Mute / Dimmer
CH/Page Up	CH+ / Page+
CH/Page Down	CH- / Page-
Pause	Pause / Step / Freeze
I<<	I<< / Preset-
>>I	>>I / Preset+
Play	Play / Slow
<<	<< / Tune-





Original	Replacement
>>	>> / Tune+
Stop	Stop / Hold
Rec	Rec / Rec Mode
Info	Info / Angle
Sleep	Sleep / Timer
AVR	Smart / List
Audio Effects	Audio / Lang I/II
Video Modes	Picture / Format
Surround Modes	Eject / Surround
Cable/SAT	Shift + 0
Blu-ray	Shift + 2
iPod	Shift + 4
Radio	Shift + 6
TV	Shift + 1
AUX	Shift + 7
DVR	Shift + 3
Game	Shift + 8

Original	Replacement
Media Server	Shift + 9
Network	Shift + 5

