









































































Original	Replacement	Original	Replacement
 Standby/On	 Power	 <<	 <<
 Open/Close	 Eject	 >>	 >>
 DVD	 Smart	 <<	 <<
 HDD	 Media	 Stop	 Stop
 USB	 Shift + Media	 Play	 Play
 Input Sel	 Subt	 Pause	 Pause
 1	 1	 >>	 >>
 2	 2	 Tv Vol+	 Vol +
 3	 3	 Tv Vol-	 Vol -
 4	 4	 Tv Mute	 Mute
 5	 5	 Audio	 Dual
 6	 6	 DTV/Analog	 Format
 7	 7	 Prog+	 Ch +
 8	 8	 Prog-	 Ch -
 9	 9	 Menu	 Menu
 0	 0	 Return	 Back
 Tv/DVD	 TV/R	 Up	 Up







































Original	Replacement
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Title List/Disc Menu	 List
 Info	 Info
 Exit	 Exit
 Play List/Title Menu	 D. Menu
 Red/Subtitle	 Red
 Green/Rec	 Green
 Yellow/ALT	 Yellow
 Blue/FAV List	 Blue
 Guide	 Guide
 Marker/Tv/Radi	 3D
 Repeat/Timer	 AV
 Text	 Text
 Rec	 Rec

Original	Replacement
 Rec Pause/Time Shift	 Shift + Pause





Original	Replacement	Original	Replacement
 Tv Standby/On	 Power		
 Input Sel	 AV		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Tv Mute	 Mute		
 Tv Vol+	 Vol +		
 Tv Vol-	 Vol -		
 Prog+	 Ch +		
 Prog-	 Ch -		

