


































































| Original | Replacement |
|---|---|
|  Power |  Power |
|  Volume Up |  Vol + |
|  Volume Down |  Vol - |
|  Sleep |  Sleep |
|  Timer Standby |  Shift + Power |
|  Band |  Green |
|  Mono Tuner |  TV/R |
|  Mode Display |  Info |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |

| Original | Replacement |
|--|---|
|  0 |  0 |
|  CD |  Yellow |
|  +10 |  Guide |
|  Tape |  Blue |
|  Video1/DAT |  Smart |
|  Video 2/AUX |  Media |
|  DSP |  3D |
|  PRGM/Test |  Menu |
|  GEQ |  Back |
|  Manual/Mode |  Pre Ch |
|  Mute |  Mute |
|  Volume Select |  Dual |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Direct |  Options |

























| Original | Replacement |
|--|---|
|  Power |  Power |
|  Volume Up |  Vol + |
|  Volume Down |  Vol - |
|  Mute |  Mute |
|  Band |  Green |
|  CD |  Yellow |
|  Tape |  Blue |
|  Video1/DAT |  Smart |
|  Video2/AUX |  Media |
|  Repeat |  Text |
|  Random |  AV |
|  Disc Skip |  Info |
|  Disc Direct Play 1 |  Shift + 1 |
|  Disc Direct Play 2 |  Shift + 2 |
|  Disc Direct Play 3 |  Shift + 3 |
|  1 |  1 |
|  2 |  2 |

| Original | Replacement |
|--|--|
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  +10 |  Guide |
|  PRGM CD |  Menu |
|  Play/Pause |  Play |
|  Stop/Clear |  Stop |
|  Search/Check |  >> |
|  I<< |  I<< |
|  Edit AI |  Format |
|  Edit PRGM |  3D |
|  <> Deck 1 |  Pause |





| Original | Replacement |
|---|--|
|  Power |  Power |
|  Volume Up |  Vol + |
|  Volume Down |  Vol - |
|  Mute |  Mute |
|  Band |  Green |
|  CD |  Yellow |
|  Tape |  Blue |
|  Video1/DAT |  Smart |
|  Video2/AUX |  Media |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |

| Original | Replacement |
|--|---|
|  9 |  9 |
|  0 |  0 |
|  +10 |  Guide |
|  PRGM DAT |  Menu |
|  <> Deck 2 |  Play |
|  Stop Deck 2 |  Stop |
|  >> Deck 2 |  >> |
|  << Deck 2 |  << |
|  Rec/Rec Mute |  Rec |
|  Pause |  Pause |

