






Original	Replacement	Original	Replacement
	Power		Power
	Tv/Radio		TV/Radio /
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	Hold		Shift + Stop /
	TVG		Guide / EPG / -/--
	Audio		Audio / Lang I/II
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Size		Zoom / Size
	<<		<< / Tune-
	Subpage		Eject / Surround
	>>		>> / Tune+

Original	Replacement	Original	Replacement
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	I<<		I<< / Preset-
	FAV		Fav / Marker / PC
	>>I/Index		>>I / Preset+
	Menu		Menu / Home
	Up		Up
	Source		AV / Input / RDS
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Exit		Exit / Cancel / Clear
	Aspect		Picture / Format
	Vol+		Vol+
	Mute		Mute / Dimmer
	CH+		CH+ / Page+





Original	Replacement
Vol-	Vol-
Display	Display / Media
CH-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/-	+ Shift + Guide / EPG / -/-
0	0
Recall	Back / Return

Original	Replacement

