


































































Original	Replacement	Original	Replacement
 Audio	 Audio / Lang I/II	 Pause/T	 Pause / Step / Freeze
 []	 Picture / Format	 M	 Menu / Home
 Power	 Power	 E	 Exit / Cancel / Clear
 PIP	 Zoom / Size	 Info	 Info / Angle
 V=	 D.Menu / Top	 Up	 Up
 [≡]	 Guide / EPG / -/--	 Left	 Left
 Mute	 Mute / Dimmer	 OK	 OK
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Red	 Red / Netflix / Search
 4	 4	 Blue	 Blue / Prime Video / Random
 5	 5	 Green	 Green / APP / Repeat
 6	 6	 Yellow	 Yellow / YouTube / Repeat
 7	 7		
 8	 8		
 9	 9		
 0	 0		





























































Original	Replacement
 Audio	 Audio / Lang I/II
 []	 Picture / Format
 Power	 Power
 SV/[*]	 Zoom / Size
 LP/V=	 Setup / OPT /
 000/[≡I]	 Guide / EPG / -/--
 Timer/Mute	 Sleep / Timer
 Timer/Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Replacement
 0	 0
 Pause/T	 Pause / Step / Freeze
 M	 Menu / Home
 E	 Exit / Cancel / Clear
 Rec/i	 Info / Angle
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 <<	 << / Tune-
 >>	 >> / Tune+
 Stop	 Stop / Hold
 Play	 Play / Slow





Original	Replacement	Original	Replacement
	Audio		Audio / Lang I/II
	[]		Picture / Format
	Power		Power
	SV		Display / Media
	LP		Smart / List
	Timer		TV/Radio /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	000		0
	M		Menu / Home
	E		Exit / Cancel / Clear
	Rec		Rec / Rec Mode
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	<<		<< / Tune-
	>>		>> / Tune+
	Stop		Stop / Hold
	Play		Play / Slow

