





































































Original	Replacement	Original	Replacement
 Standby	 Power	 Menu	 Menu / Home
 Mute	 Mute / Dimmer	 EPG	 Guide / EPG / -/-
 1	 1	 Exit	 Exit / Cancel / Clear
 2	 2	 Up	 Up
 3	 3	 CH+	 CH+ / Page+
 4	 4	 Left	 Left
 5	 5	 OK	 OK
 6	 6	 Right	 Right
 7	 7	 Vol+	 Vol+
 8	 8	 Down	 Down
 9	 9	 CH-	 CH- / Page-
 FAV	 Fav / Marker / PC	 Text	 Text / Goto
 0	 0	 Red	 Red / Netflix / Search
 Recall	 Back / Return	 Green	 Green / APP / Repeat
 Audio	 Audio / Lang I/II	 Pause	 Pause / Step / Freeze
 Subtitle	 Subtitle / EQ	 Tv/Radio	 TV/Radio /
 Info	 Info / Angle		



