








































































Original	Replacement
	 Power
	 Mute
	 Shift + Red
	 Shift + Yellow
	 Shift + Green
	 Shift + Blue
	 AV
	 Format
	 Dual
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8



































Original	Replacement
	 9
	 0
	 Guide
	 Media
	 Pre Ch
	 Text
	 Menu
	 Exit
	 Info
	 Vol +
	 Vol -
	 Ch +
	 Ch -
	 Up
	 Down
	 Right
	 Left







Original	Replacement
 Power	 Power
 TV	 Shift + Red
 REC	 Shift + Green
 SP	 Shift + Yellow
 AUDIO	 Shift + Blue
 Timer/IN-Mode	 AV
 >[ ]</5/7CH	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AV	 0



































Original	Replacement
 EPG/Bass	 Guide
 Media/Surr	 Media
 PIP/AUX	 Pre Ch
 Text	 Text
 Menu	 Menu
 End	 Exit
 Info	 Info
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red/Music	 Red
 Green/Movie	 Green
 Yellow/Show	 Yellow









Original	Replacement
 Power	 Power
 TV	 Shift + Red
 REC	 Shift + Green
 SP	 Shift + Yellow
 AUDIO	 Shift + Blue
 Mute	 Mute
 Timer/IN-Mode	 AV
 >[ ]</5/7/CH (1)	 Format
 Sound	 Dual
 EPG/Bass (1)	 Guide
 Media/Surr	 Media
 Sound1	 1
 Sound2	 2
 Sound3	 3
 Sound4	 4
 >[ ]</5/7/CH (2)	 Shift + Format
 EPG/Bass (2)	 5


































Original	Replacement
 EPG/Bass (3)	 6
 PIP/AUX (1)	 Pre Ch
 PIP/AUX (2)	 Shift + 1
 PIP/AUX (3)	 Shift + 2
 PIP/AUX (4)	 Shift + 3
 PIP/AUX (5)	 Shift + 4
 PIP/AUX (6)	 Shift + 5
 PIP/AUX (7)	 Shift + 6
 Text	 Text
 Menu	 Menu
 End	 Exit
 Info	 Info
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left











































Original	Replacement
 Power	 Power
 TV	 Shift + Red
 REC	 Shift + Green
 SP	 Shift + Yellow
 AUDIO	 Shift + Blue
 Timer/IN-Mode	 AV
 >[ ]</5/7/CH	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AV	 0

Original	Replacement
 EPG/Bass	 Guide
 Media/Surr	 Media
 PIP/AUX	 Pre Ch
 Text	 Text
 Menu	 Menu
 End	 Exit
 Info	 Info
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red/Music	 Red
 Green/Movie	 Green
 Yellow/Show	 Yellow



