






















Original	Replacement	Original	Replacement
 Stereo	 Dual	 Select	 Ok
 Level	 Media	 Menu	 D. Menu
 Delay	 Options	 Display	 Info
 Surround	 Subt	 Disc/Deck 1/2	 Menu
 TV	 TV/R	 Tv/AV	 AV
 CD	 Yellow	 +	 Ch +
 DVD	 Blue	 -	 Ch -
 Tuner/Band	 Green	 Test	 Text
 Tape	 Red	 Power TV	 Power
 VCR	 Smart	 Tv Vol Up	 Shift + Vol +
 Vol+	 Vol +	 Tv Vol Down	 Shift + Vol -
 Vol-	 Vol -	 1 Tv	 1
 Muting	 Mute	 2 Tv	 2
 Up	 Up	 3 Tv	 3
 Down	 Down	 4 Tv	 4
 Right	 Right	 5 Tv	 5
 Left	 Left	 6 Tv	 6






Original	Replacement	Original	Replacement
 Power DVD	 Power	 Menu	 D. Menu
 Level	 Media	 Up	 Up
 Delay	 Options	 Down	 Down
 Surround	 Subt	 Right	 Right
 Stereo	 Dual	 Left	 Left
 TV	 TV/R	 Select	 Ok
 VCR	 Smart	 Test	 Text
 Tuner/Band	 Green	 +	 Ch +
 Tape	 Red	 -	 Ch -
 CD	 Yellow	 1 DVD	 1
 DVD	 Blue	 2 DVD	 2
 Play DVD	 Play	 3 DVD	 3
 I<</<< DVD	 <<	 4 DVD	 4
 Stop DVD	 Stop	 5 DVD	 5
 >>/>>I DVD	 >>	 6 DVD	 6
 Disc/Deck 1/2	 Menu	 7 DVD	 7
 Display	 Info	 8 DVD	 8









































































Original	Replacement	Original	Replacement
 Power CD	 Power	 Disc/Deck 1/2	 Menu
 Level	 Media	 Up	 Up
 Surround	 Subt	 Down	 Down
 Delay	 Options	 Right	 Right
 Stereo	 Dual	 Left	 Left
 TV	 TV/R	 Select	 Ok
 VCR	 Smart	 Test	 Text
 CD	 Yellow	 +	 Ch +
 DVD	 Blue	 -	 Ch -
 Tape	 Red	 Vol+	 Vol +
 Tuner/Band	 Green	 Vol-	 Vol -
 Stop CD	 Stop	 Muting	 Mute
 I<</<< CD	 <<	 Power Tape	 Shift + Power
 >>/>>I CD	 >>	 Stop Tape	 Shift + Stop
 Play CD	 Play	 Play Tape	 Shift + Play
 Menu	 D. Menu	 I<</<< Tape	 Shift + <<
 Display	 Info	 >>/>>I Tape	 Shift + >>









Original		Replacement		Original		Replacement	
	Power VCR		Power		3 VCR		3
	Level		Media		4 VCR		4
	Delay		Options		5 VCR		5
	Surround		Subt		6 VCR		6
	Stereo		Dual		7 VCR		7
	VCR		Smart		8 VCR		8
	Tape		Red		9 VCR		9
	TV		TV/R		0 VCR		0
	CD		Yellow		>10/-/- VCR		Guide
	DVD		Blue		Direct Tuning/Disc Enter		List
	Tuner/Band		Green		Vol+		Vol +
	Stop		Stop		Vol-		Vol -
	I<</<<		<<		Muting		Mute
	>>/>>I		>>		Up		Up
	Play		Play		Down		Down
	1 VCR		1		Right		Right
	2 VCR		2		Left		Left





Original	Replacement
 Select	 Ok
 Disc/Deck 1/2	 Menu
 Display	 Info
 Menu	 D. Menu
 Test	 Text
 +	 Ch +
 -	 Ch -
 Power Tuner/Band	 Shift + Power
 1 Tuner/Band	 Shift + 1
 2 Tuner/Band	 Shift + 2
 3 Tuner/Band	 Shift + 3
 4 Tuner/Band	 Shift + 4
 5 Tuner/Band	 Shift + 5
 6 Tuner/Band	 Shift + 6
 7 Tuner/Band	 Shift + 7
 8 Tuner/Band	 Shift + 8
 9 Tuner/Band	 Shift + 9

Original	Replacement
 0 Tuner/Band	 Shift + 0
 >10/-/-	 Shift + Guide

