Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
	Recall	PC FAV MARKER	Fav / Marker / PC
DISP	Disp	MEDIA DISPLAY	Display / Media
INPUT	Input	RDS AV INPUT	AV / Input / RDS
ZOOM	Zoom	SIZE ZOOM	Zoom / Size

Originalfernbedienung		Ersatzfernbedienung	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
+ VOL	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
+ CH	CH+	+ CH PAGE	CH+ / Page+
CH -	CH-	CH PAGE -	CH- / Page-
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	OK
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
PMODE	P. Mode	FORMAT PICTURE	Picture / Format
SMODE	S. Mode	TITLE SOUND	Sound / Title
AUTO	Auto	LIST SMART	Smart / List
ANGLE	Angle	ANGLE INFO	Info / Angle
	<<	PRESET-	<< / Preset-

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	>>I	PRESET+	>>I / Preset+		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	Open/Close	SURROUND	Eject / Surround		
	Play/Pause	SLOW	Play / Slow		
	II>/Step	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		
SETUP	Red/Setup	NETFLIX SEARCH	Red / Netflix / Search		
MENU	Green/Menu	APP REPEAT	Green / APP / Repeat		
TITLE	Yellow/Title	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
LANG	Blue/Lang	Prime Video RANDOM	Blue / Prime Video / Random		

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power	Power	CH-	CH- / Page-
Mute	Mute / Dimmer	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	Enter	OK
5	5	Menu	Menu / Home
6	6	Exit	Exit / Cancel / Clear
7	7	Zoom	Zoom / Size
8	8	P. Mode	Picture / Format
9	9	S. Mode	Sound / Title
0	0	Angle	Info / Angle
-/--	Guide / EPG / -/--	Red/Setup	Red / Netflix / Search
Recall	Fav / Marker / PC	Green/Menu	Green / APP / Repeat
Vol +	Vol +	Yellow/Title	Yellow / YouTube / Repeat
Vol -	Vol -	Blue/Lang	Blue / Prime Video / Random
CH+	CH+ / Page+	Disp	Display / Media