Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power Receiver	Power	CD	Shift + 3
1	1	D.TUN	Smart / List
VCR / DVR	Shift + 4	Dimmer	Shift + Mute / Dimmer
2	2	0	0
CBL / SAT	Shift + 0	Sleep	Sleep / Timer
3	3	CH+	CH+ / Page+
4	4	Vol +	Vol +
AUX	Shift + 7	CH-	CH- / Page-
5	5	Vol -	Vol -
Multi CH	Shift + 1	SP A/B	Info / Angle
6	6	Up	Up
DVD	Shift + 2	Muting	Mute / Dimmer
7	7	Left	Left
TAPE	Shift + 5	Enter	OK
8	8	Right	Right
TUNER	Shift + 6	Setup	Setup / OPT /
9	9	Down	Down

Originalfernbedienung		Ersatzfernbedienung	
RETURN	Return	RETURN BACK	Back / Return
	Pause / Play Rev	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
AUDIO TEST TONE	Test Tone	NETFLIX SEARCH	Red / Netflix / Search
SUBTITLE CH SEL	CH Sel	APP REPEAT	Green / APP / Repeat
RANDOM LEVEL-	Level -	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT LEVEL+	Level +	Prime Video RANDOM	Blue / Prime Video / Random
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Originalfernbedienung		Ersatzfernbedienung	
L NIGHT DVD	L. Night	HOME MENU	Menu / Home
CINE FLTR HDD	Cine FLTR	TOP MENU D.MENU	D.Menu / Top

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	Power		Power		Left / Playlist / Ca		Left
	1		1		Enter		OK
	2		2		Right / Playlist / C		Right
	3		3		Setup		Setup / OPT /
	4		4		Down		Down
	5		5		Return		Back / Return
	6		6		Pause		Pause / Step / Freeze
	7		7		Play		Play / Slow
	8		8		Stop		Stop / Hold
	9		9		<<		<< / Tune-
	+10 / 10 / - / --		Guide / EPG / -/--		>>		>> / Tune+
	0 / 11		0		I<<		I<< / Preset-
	CLR / 12 / Sleep		Sleep / Timer		>>I		>>I / Preset+
	CLR / 12 / Sleep		Exit / Cancel / Clear		Stereo		Sound / Title
	Guide / Top		D.Menu / Top		Surround		Eject / Surround
	Up		Up		< Listening Mode		Shift + I<< / Preset-
	Previous Menu / Muting		Menu / Home		Listening Mode >		Shift + >>I / Preset+

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
AUDIO / TEST TONE	Audio	LANG I/II / AUDIO	Audio / Lang I/II		
SUBTITLE / CH SEL	Subtitle	EQ / SUBTITLE	Subtitle / EQ		
RANDOM / LEVEL-	Level - / Random	Prime Video / RANDOM	Blue / Prime Video / Random		
REPEAT / LEVEL+	Level + / Repeat	APP / REPEAT	Green / APP / Repeat		
DISPLAY	Display	MEDIA / DISPLAY	Display / Media		
PLAY MODE / VCR	Play Mode VCR	SHIFT + VIDEO 4	Shift + 4		
L NIGHT / DVD	Play Mode DVD	SHIFT + DVD 2	Shift + 2		
CINE FLTR / HDD	Play Mode HDD	SHIFT + AUX-HDD 7	Shift + 7		

Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	+10/ 10/ -/ --		Guide / EPG / -/--
	0		0
	CLR/ 12/ Sleep		Sleep / Timer
	CLR/ 12/ Sleep		Exit / Cancel / Clear
	Disc/ Album		CH+ / Page+
	Vol +		Vol +
	Disc/ Album CH-		CH- / Page-

Originalfernbedienung		Ersatzfernbedienung	
	Vol -		Vol -
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
STEREO	Stereo		Audio / Lang I/II
SURROUND	Surround		Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
RANDOM LEVEL-	Level -/ Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Level +/ Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Originalfernbedienung		Ersatzfernbedienung	
STANDBY/ON	Standby / On		Power
VCR/DVR	VCR/DVR	VIDEO 4	4
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
AUX	AUX	AUX - HDD 7	7
MULTI CH	Multi CH	TV 1	1
DVD	DVD	DVD 2	2
TAPE	Tape	TAPE 5	5
TUNER	Tuner	TUNER 6	6
CD	CD	CD - STB 3	3
D.Tun	D.Tun	LIST SMART	Smart / List
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CLR SLEEP	CLR / Sleep	TIMER SLEEP	Sleep / Timer
CLR SLEEP	CLR / Sleep	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH DISC ALBUM	CH Disc	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
CH DISC ALBUM	CH Disc Album	CH PAGE -	CH- / Page-
VOL	Vol -	VOL -	Vol -

Originalfernbedienung		Ersatzfernbedienung	
	Up		Up
PREVIOU MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT	Left/Playlist/Ca		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT	Right/Playlist/C		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
	Rev. Play	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	PRESET-	I<< / Preset-
	Listening Mode >	PRESET+	>>I / Preset+

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
AUDIO / TEST TONE	Test Tone	NETFLIX / SEARCH	Red / Netflix / Search		
SUBTITLE / CH SEL	CH Sel	APP / REPEAT	Green / APP / Repeat		
RANDOM / LEVEL-	Level -	YouTube / REPEAT A-B	Yellow / YouTube / Repeat		
REPEAT / LEVEL+	Level +	Prime Video / RANDOM	Blue / Prime Video / Random		
DISPLAY	Display	MEDIA / DISPLAY	Display / Media		
L.NIGHT / DVD	L.Night / Play Mode DVD	HOME / MENU	Menu / Home		
CINE FLTR / HDD	Cine FLTR / Play Mode HDD	TOP MENU / D.MENU	D.Menu / Top		