Original		Replacement	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO CAL	Auto Cal	LIST SMART	Smart / List
SYSTEM	Tv Power	SHIFT +	Shift + Power
STANDBY	System Standby		Power
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5
VIDEO 3	Video 3	SHIFT + AUX - HDD 7	Shift + 7
DVD	DVD	SHIFT + DVD 2	Shift + 2
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
TV	TV	SHIFT + TV 1	Shift + 1
SA-CD/CD	SA-CD / CD	SHIFT + CD - STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
2CH	2 CH	NETFLIX SEARCH	Red / Netflix / Search
A.F.D.	AFD	APP REPEAT	Green / APP / Repeat
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1

Original		Replacement	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
FM MODE	FM Mode	PROGRAM TV/RADIO	TV/Radio /
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
D.TUNING	D.Tuning	SURROUND	Eject / Surround
0/10	0 / 10	HDMI - SAT 0	0
MEMORY ENTER	Enter / Memory	PC FAV MARKER	Fav / Marker / PC
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Left		Left
	OK	OK	OK

Original	Replacement	Original	Replacement
Right	Right		
Master Vol +	Vol +		
Tv Vol +	Shift + Vol +		
Down	Down		
Menu	Menu / Home		
Master Vol -	Vol -		
Tv Vol -	Shift + Vol -		
I<< / Preset -	I<< / Preset-		
Tv CH-	Shift + CH- /		
>>I / Preset +	>>I / Preset+		
Tv CH+	Shift + CH+ /		
<< / Tuning -	<< / Tune-		
>> / Tuning +	>> / Tune+		

Original		Replacement		Original		Replacement	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer	2	2	DVD 2	2
AUTO CAL	Auto Cal	LIST SMART	Smart / List	3	3	CD-STB 3	3
SYSTEM	Power AV	SHIFT +	Shift + Power	4	4	VIDEO 4	4
STANDBY	Power		Power	5	5	TAPE 5	5
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4	6	6	TUNER 6	6
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5	FM MODE	FM Mode	PROGRAM TV/RADIO	TV/Radio /
VIDEO 3	Video 3	SHIFT + AUX-HDD 7	Shift + 7	7	7	AUX-HDD 7	7
DVD	DVD	SHIFT + DVD 2	Shift + 2	8	8	USB 8	8
SAT	SAT	SHIFT + HDMI-SAT 0	Shift + 0	9	9	BLUETOOTH 9	9
TV	TV	SHIFT + TV 1	Shift + 1	D.TUNING	D.Tuning/D.Skip	SURROUND	Eject / Surround
SA-CD/CD	SA-CD / CD	SHIFT + CD-STB 3	Shift + 3	>10/• -/-- CLEAR	-/--/>10	-/-- GUIDE EPG	Guide / EPG / -/--
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6	0/10	0/10	HDMI-SAT 0	0
2CH	2CH	NETFLIX SEARCH	Red / Netflix / Search	MEMORY ENTER	Enter/Memory	PC FAV MARKER	Fav / Marker / PC
A.F.D.	A.F.D.	APP REPEAT	Green / APP / Repeat	D.SKIP DVD MENU	DVD Menu	TOP MENU D.MENU	D.Menu / Top
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat	DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random	TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1	MUTING	Muting	DIMMER MUTE	Mute / Dimmer

Original	Replacement	Original	Replacement
Up	Up	Pause	Pause / Step / Freeze
Left	Left	Stop	Stop / Hold
OK	OK		
Right	Right		
Vol +	Vol +		
Return/Exit	Back / Return		
Return/Exit	Exit / Cancel / Clear		
Down	Down		
Menu	Menu / Home		
Vol -	Vol -		
I<</Preset-	I<< / Preset-		
←/Replay	Shift + I<< / Preset-		
·→/Advance	Shift + >>I / Preset+		
>>I/Preset+	>>I / Preset+		
<</Tuning-	<< / Tune-		
Play	Play / Slow		
>>/Tuning+	>> / Tune+		

Original		Replacement	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO CAL	Auto Cal	LIST SMART	Smart / List
SYSTEM	Power AV	SHIFT +	Shift + Power
STANDBY	Power		Power
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5
VIDEO 3	Video 3	SHIFT + AUX - HDD 7	Shift + 7
DVD	DVD	SHIFT + DVD 2	Shift + 2
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
TV	TV	SHIFT + TV 1	Shift + 1
SA-CD/CD	SA-CD/CD	SHIFT + CD - STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
2CH	2CH	NETFLIX SEARCH	Red / Netflix / Search
A.F.D.	A. F. D.	APP REPEAT	Green / APP / Repeat
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1

Original		Replacement	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
FM MODE	FM Mode	PROGRAM TV/ RADIO	TV/ Radio /
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
D.TUNING	D. Tuning/ D. Skip	SURROUND	Eject / Surround
>10/• -/-- CLEAR	-/--/>10	-/-- GUIDE EPG	Guide / EPG / -/--
0/10	0/10	HDMI - SAT 0	0
MEMORY ENTER	Enter/ Memory	PC FAV MARKER	Fav / Marker / PC
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Left		Left

Original		Replacement		Original		Replacement	
	OK		OK				
	Right		Right				
	Vol +		Vol +				
	Down		Down				
	Menu		Menu / Home				
	Vol -		Vol -				
	I<</Preset-		I<< / Preset-				
	>>I/Preset+		>>I / Preset+				
	<</Tuning-		<< / Tune-				
	Play		Play / Slow				
	>>/Tuning+		>> / Tune+				
	Pause		Pause / Step / Freeze				
	Stop		Stop / Hold				

Original		Replacement		Original		Replacement	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer	2	2	DVD 2	2
AUTO CAL	Auto Cal	LIST SMART	Smart / List	3	3	CD - STB 3	3
SYSTEM	Power AV	SHIFT +	Shift + Power	4	4	VIDEO 4	4
STANDBY	Power	Power		5	5	TAPE 5	5
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4	6	6	TUNER 6	6
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5	FM MODE	FM Mode	PROGRAM TV/RADIO	TV/Radio /
VIDEO 3	Video 3	SHIFT + AUX - HDD 7	Shift + 7	7	7	AUX - HDD 7	7
DVD	DVD	SHIFT + DVD 2	Shift + 2	8	8	USB 8	8
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0	9	9	BLUETOOTH 9	9
TV	TV	SHIFT + TV 1	Shift + 1	D.TUNING	D.Tuning	SURROUND	Eject / Surround
SA-CD/CD	SA-CD / CD	SHIFT + CD - STB 3	Shift + 3	0/10	0/10	HDMI - SAT 0	0
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6	MEMORY ENTER	Enter/Memory	PC FAV MARKER	Fav / Marker / PC
2CH	2CH	NETFLIX SEARCH	Red / Netflix / Search	DISPLAY	Display	MEDIA DISPLAY	Display / Media
A.F.D.	A.F.D.	APP REPEAT	Green / APP / Repeat	TOOLS	Tools	OPT - TOOLS SETUP	Setup / OPT /
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat	MUTING	Muting	DIMMER MUTE	Mute / Dimmer
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random		Up		Up
1	1	TV 1	1		Left		Left

Original		Replacement		Original		Replacement	
	OK		OK				
	Right		Right				
	Vol +		Vol +				
	Down		Down				
	Menu		Menu / Home				
	Vol -		Vol -				
	Preset -		I << / Preset -				
	Preset +		>>I / Preset +				
	Tuning-		<< / Tune-				
	Tuning+		>> / Tune+				