Mandis shop

# QUESTAR DV900

| Original | Replacement |
|---|---|
| Power | Power |
| Open/Close | Eject / Surround |
| Mute | Mute / Dimmer |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| Info | Info / Angle |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| Clear | SHIFT + EXIT Shift + Exit / Cancel / Clear |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Video | SHIFT + 4 Shift + 4 |
| 0 | 0 |
| Menu | Menu / Home |

| Original | Replacement |
|---|---|
| Title | Sound / Title |
| Exit | Exit / Cancel / Clear |
| << | << / Tune- |
| >> | >> / Tune+ |
| Zoom | Zoom / Size |
| Left | Left |
| Up | Up |
| Right | Right |
| >>I | >>I / Preset+ |
| OK | OK |
| Down | Down |
| I<< | I<< / Preset- |
| Stop | Stop / Hold |
| Play | Play / Slow |
| Pause | Pause / Step / Freeze |
| ≡ | D.Menu / Top |

https://remotecontrols.dk/en/1060791-82313-replacement-remote-control-for-QUESTAR-DV900.html