Original		Replacement	
	Power		Power
	V-Mode	TOP MENU D.MENU	D.Menu / Top
	Mute	DIMMER MUTE	Mute / Dimmer
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
SAT	SAT	MEDIA DISPLAY	Display / Media
TV/AV	TV / AV	RDS AV INPUT	AV / Input / RDS
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
PAUSE	Pause	STEP - FREEZE II	Pause / Step / Freeze
7	7	AUX - HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PAGE+	Page +	SHIFT + CH PAGE +	Shift + CH+ /
TV/RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
0	0	HDMI - SAT 0	0
←PR	<-- PR	RETURN BACK	Back / Return
PAGE-	Page -	SHIFT + CH PAGE −	Shift + CH- /
PR+	Up / PR +	CH PAGE +	CH+ / Page+
PR+	Up / PR +		Up
	Left / Vol -		Left
	Left / Vol -	VOL −	Vol-
OK LIST	OK / List	LIST SMART	Smart / List
OK LIST	OK / List	OK	OK
	Right / Vol +		Right
	Right / Vol +	VOL +	Vol+
PR-	Down / PR -	CH PAGE −	CH- / Page-
PR-	Down / PR -		Down

Original	Replacement
Menu	Menu / Home
Exit	Exit / Cancel / Clear
Info	Info / Angle
EPG	Guide / EPG / -/--
Red / Find	Red / Netflix / Search
Green / V-Format	Picture / Format
Green / V-Format	Green / APP / Repeat
Yellow / TXT	Text / Goto
Yellow / TXT	Yellow / YouTube / Repeat
Blue / Audio	Audio / Lang I/II
Blue / Audio	Blue / Prime Video / Random
Record	Rec / Rec Mode
Play	Play / Slow
Stop	Stop / Hold
Shift	Setup / OPT /
<< Fast	<< / Tune-
>> Fast	>> / Tune+

Original	Replacement
< Slow	I<< / Preset-
> Slow	>>I / Preset+