Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
PIC MODE	PIC Mode	V-FOR	V-FOR
PIC SIZE	PIC Size	WIDE	WIDE
SLEEP	Sleep	SHIFT +	Shift + Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 100	--/+10/100	EPG	-/-- / EPG
INPUT	Input	SRC	SRC
TOP MENU FAV BROWSER	FAV Browser/Top Menu	MEDIA	MEDIA

Originalfernbedienung		Ersatzfernbedienung	
RECALL	Recall	BACK	BACK
+ VOL	Vol +	+ VOL	VOL +
VOL −	Vol -	VOL −	VOL -
MUTE	Mute		MUTE
▲ CH	CH+	+ CH	CH +
CH ▼	CH-	CH −	CH -
DVD RTN CH RTN	CH RTN/DVD	FAV 2. P/C	P/C / FAV
SET UP GUIDE	Guide/Set Up	SHIFT + EPG 1. -/--	Shift + -/-- / EPG
INFO	Info	INFO	INFO
	Up	▲	UP
	Down	▼	DOWN
NEXT	Right/Next [CB]	▶	RIGHT
BACK	Left/Back [CB]	◀	LEFT
ENTER	Enter	OK	OK
MENU	Menu	MENU	MENU
DVD CLEAR EXIT	Exit/DVD Clear	EXIT	EXIT
PAUSE/STEP	Pause/Step	⏸	Pause

Originalfernbedienung		Ersatzfernbedienung	
PLAY	Play		Play
STOP	Stop		Stop
SKIP	I<<		First
REW	<<		Rewind
FF	>>		Fast Forward
SKIP	>>I		Last
REC	Rec		Rec
EJECT	Eject	C	Yellow (C)
SLO	<I Slow	A	Red (A)
LOW	Slow I>	B	Green (B)
TV/VCR SEARCH	Tv/VCR/Search	TV/R	TV/R
ANGLE	Camera/Angle	OPT+	OPT+
SUB TITLE	[...]/Subtitl		Subt.
AUDIO	O))/Audio		Audio

Originalfernbedienung	Ersatzfernbedienung

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
SLEEP	Sleep	SHIFT +	Shift + Power
PIC SIZE	PIC Size	WIDE	WIDE
PIC MODE	PIC Mode	V-FOR	V-FOR
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
INPUT	Input	SRC	SRC
+10 100	--/+10/100	EPG	-/-- / EPG
MUTE	Mute		MUTE

Originalfernbedienung		Ersatzfernbedienung	
+ VOL	Vol +	+ VOL	VOL +
VOL −	Vol -	VOL −	VOL -
CH ▲	CH+	+ CH	CH +
CH ▼	CH-	CH −	CH -
RECALL	Recall	BACK	BACK
INFO	Info	INFO	INFO
SET UP GUIDE	Guide/Set Up	SHIFT + EPG 1. -/--	Shift + -/-- / EPG
MENU	Menu	MENU	MENU
DVD CLEAR EXIT	Exit/DVD Clear	EXIT	EXIT
ENTER	Enter	OK	OK
▲	Up	▲	UP
▼	Down	▼	DOWN
NEXT ▶	Right/Next [CB]	▶	RIGHT
BACK ◀	Left/Back [CB]	◀	LEFT

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
PIC SIZE	PIC Size	WIDE	WIDE
PIC MODE	PIC Mode	V-FOR	V-FOR
SLEEP	Sleep	SHIFT +	Shift + Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 100	-- / +10/ 100	EPG	-/-- / EPG
INPUT	Input	SRC	SRC
MUTE	Mute		MUTE

Originalfernbedienung		Ersatzfernbedienung	
+ VOL	Vol +	+ VOL	VOL +
VOL −	Vol -	VOL −	VOL -
CH	CH+	+ CH	CH +
CH	CH-	CH −	CH -
RECALL	Recall	BACK	BACK
PAUSE/STEP	Pause/Step		Pause
PLAY	Play		Play
STOP	Stop		Stop
REW	<<		Rewind
FF	>>		Fast Forward
TV/VCR SEARCH	Tv/VCR/Search	TV/R	TV/R

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
PIC SIZE	PIC Size	WIDE	WIDE
PIC MODE	PIC Mode	V-FOR	V-FOR
SLEEP	Sleep	SHIFT +	Shift + Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 100	--/+10/100	EPG	-/-- / EPG
INPUT	Input	SRC	SRC
TOP MENU FAV BROWSER	FAV Browser/Top Menu	MEDIA	MEDIA

Originalfernbedienung		Ersatzfernbedienung	
MUTE	Mute	MUTE	MUTE
+ VOL	Vol +	+ VOL	VOL +
VOL –	Vol -	VOL –	VOL -
SET UP GUIDE	Guide/Set Up	SHIFT + EPG	Shift + -/-- / EPG
MENU	Menu	MENU	MENU
DVD CLEAR EXIT	Exit/DVD Clear	EXIT	EXIT
INFO	Info	INFO	INFO
RECALL	Recall	BACK	BACK
DVD RTN CH RTN	CH RTN/DVD	FAV 2. P/C	P/C / FAV
ENTER	Enter	OK	OK
	Up		UP
	Down		DOWN
NEXT	Right/Next [CB]		RIGHT
BACK	Left/Back [CB]		LEFT
PAUSE/STEP	Pause/Step		Pause
PLAY	Play		Play
STOP	Stop		Stop

Originalfernbedienung		Ersatzfernbedienung	
SKIP	I <<		First
REW	<<		Rewind
FF	>>		Fast Forward
SKIP	>>I		Last
EJECT	Eject	C	Yellow (C)
TV/VCR SEARCH	Tv/VCR/Search	TV/R	TV/R
ANGLE	Camera/Angle	OPT+	OPT+
SUB TITLE	[...]/Subtitl		Subt.
AUDIO	O))/Audio		Audio

Originalfernbedienung	Ersatzfernbedienung