| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|---|---|---|---|
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer | VOLUME | Vol + | VOL + | Vol + |
| ON/STANDBY | On/Standby | | Power | CH / PAGE | CH- | CH PAGE – | CH- / Page- |
| CBL/SAT | CBL/SAT | HDMI - SAT 0 | 0 | MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| DVD | DVD | DVD 2 | 2 | VOLUME | Vol - | VOL – | Vol - |
| Blu-ray | Blu-ray | VIDEO 4 | 4 | INFO | Info | ANGLE INFO | Info / Angle |
| GAME | Game | PC FAV MARKER | Fav / Marker / PC | OPTION | Option | SHIFT + OPT-TOOLS SETUP | Shift + Setup / OPT / Tools |
| AUX | AUX | AUX - HDD 7 | 7 | OPTION | Option | HOME MENU | Menu / Home |
| MEDIA PLAYER | Media Player | MEDIA DISPLAY | Display / Media | | Up | | Up |
| TV AUDIO | TV Audio | TV 1 | 1 | | Left | | Left |
| CD | CD | CD - STB 3 | 3 | ENTER | Enter | OK | OK |
| TUNER | Tuner | TUNER 6 | 6 | | Right | | Right |
| iPod /USB | iPod/USB | USB 8 | 8 | BACK | Back | RETURN BACK | Back / Return |
| PHONO | Phono | -/-- GUIDE EPG | Guide / EPG / -/-- | | Down | | Down |
| M-XPort | M-XPort | TAPE 5 | 5 | SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| NETWORK | Network | BLUETOOTH 9 | 9 | TUNE – | I<<Tune- | PRESET- | I<< / Preset- |
| INTERNET RADIO | Internet Radio | LIST SMART | Smart / List | TUNE – | I<<Tune- | TUNE- | << / Tune- |
| CH / PAGE | CH+ | CH PAGE + | CH+ / Page+ | | Play / Pause | SLOW | Play / Slow |

| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|---|---|
| ►/II | Play / Pause | STEP-FREEZE II | Pause / Step / Freeze | | |
| TUNE + ►►I | >>I / Tune+ | TUNE+ ►► | >> / Tune+ | | |
| TUNE + ►►I | >>I / Tune+ | PRESET+ ►►I | >>I / Preset+ | | |
| 1 | Favorite Station | TITLE SOUND | Sound / Title | | |
| 2 | Favorite Station | LANG I/II AUDIO | Audio / Lang I/II | | |
| 3 | Favorite Station | EQ SUBTITLE | Subtitle / EQ | | |
| MOVIE | Red/Movie | NETFLIX SEARCH | Red / Netflix / Search | | |
| MUSIC | Green/Music | APP REPEAT | Green / APP / Repeat | | |
| GAME | Blue/Game | Prime Video RANDOM | Blue / Prime Video / Random | | |
| PURE | Yellow/Pure | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|---|---|---|---|
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer | VOLUME | Vol + | VOL + | Vol + |
| ON/STANDBY | On/Standby | | Power | CH / PAGE | CH- | CH PAGE – | CH- / Page- |
| CBL/SAT | CBL/SAT | HDMI - SAT 0 | 0 | MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| DVD | DVD | DVD 2 | 2 | VOLUME | Vol - | VOL – | Vol - |
| Blu-ray | Blu-ray | VIDEO 4 | 4 | OPTION | Option | OPT-TOOLS SETUP | Setup / OPT / |
| GAME | Game | PC FAV MARKER | Fav / Marker / PC | OPTION | Option | HOME MENU | Menu / Home |
| AUX | AUX | AUX - HDD 7 | 7 | | Up | | Up |
| MEDIA PLAYER | Media Player | MEDIA DISPLAY | Display / Media | | Left | | Left |
| TV AUDIO | TV Audio | TV 1 | 1 | ENTER | Enter | OK | OK |
| CD | CD | CD - STB 3 | 3 | | Right | | Right |
| TUNER | Tuner | TUNER 6 | 6 | BACK | Back | RETURN BACK | Back / Return |
| iPod /USB | iPod/USB | USB 8 | 8 | | Down | | Down |
| PHONO | Phono | -/-- GUIDE EPG | Guide / EPG / -/-- | TUNE – | I<<Tune- | PRESET- | I<< / Preset- |
| M-XPort | M-XPort | TAPE 5 | 5 | TUNE – | I<<Tune- | TUNE- | << / Tune- |
| NETWORK | Network | BLUETOOTH 9 | 9 | | Play / Pause | SLOW | Play / Slow |
| INTERNET RADIO | Internet Radio | LIST SMART | Smart / List | | Play / Pause | STEP - FREEZE | Pause / Step / Freeze |
| CH / PAGE | CH+ | CH PAGE + | CH+ / Page+ | TUNE + | >>I/Tune+ | PRESET+ | >>I / Preset+ |

| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|---|---|
| TUNE+ | >>I / Tune+ | TUNE+ | >> / Tune+ | | |
| 1 | Favorite Station | TITLE SOUND | Sound / Title | | |
| 2 | Favorite Station | LANG I/II AUDIO | Audio / Lang I/II | | |
| 3 | Favorite Station | EQ SUBTITLE | Subtitle / EQ | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |