Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
STANDBY	Standby		Power		Right		Right
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	HOME	Home	HOME MENU	Menu / Home
ROTATE	Rotate	SURROUND	Eject / Surround		Down		Down
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /	INFO	Info	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	PLAY	Play	SLOW	Play / Slow
VIDEO OUT	Video Out	PROGRAM TV/RADIO	TV/Radio /	PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
DISPLAY	Display	MEDIA DISPLAY	Display / Media	STOP	Stop	HOLD	Stop / Hold
ZOOM	Zoom	SIZE ZOOM	Zoom / Size	DEVICE	Device	RDS AV INPUT	AV / Input / RDS
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II	BACKLIGHT	Backlight	LIST SMART	Smart / List
DIGEST	Digest Photo	TOP MENU D.MENU	D.Menu / Top	4:3/16:9	4:3/16:9	GOTO TEXT	Text / Goto
MODE	Mode Photo	FORMAT PICTURE	Picture / Format	VOL+	Vol +	+ VOL	Vol +
SLIDE TIME	Slide Time	TIMER SLEEP	Sleep / Timer	VOL-	Vol -	VOL −	Vol -
PHOTO+MUSIC	Photo-Music	TITLE SOUND	Sound / Title	1	1	TV 1	1
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /	2	2	DVD 2	2
	Up		Up	3	3	CD-STB 3	3
	Left		Left	+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
ENTER	Enter	OK	OK	4	4	VIDEO 4	4

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
5	5	TAPE 5	5		
6	6	TUNER 6	6		
0	0	HDMI - SAT 0	0		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
TIME SEARCH	Time Search	SHIFT +	NETFLIX SEARCH Shift + Red / Netflix /		
SKIP <<	<< Skip	TUNE- <<	<< / Tune-		
SKIP >>	Skip >>	TUNE+ >>	>> / Tune+		
PREV I<<	I<< / Prev	PRESET- I<<	I<< / Preset-		
NEXT >>I	>>I / Next	PRESET+ >>I	>>I / Preset+		
MOVIE	Movie	NETFLIX SEARCH	Red / Netflix / Search		
MUSIC	Music	APP REPEAT	Green / APP / Repeat		
PHOTO	Photo	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
FILE	File	Prime Video RANDOM	Blue / Prime Video / Random		