Mandis shop

JVC RM-RXQ1002

Originalfernbedienung		Ersatzfernbedienung	
1	1	1	1
2	2	2	2
3	3	3	3
(AC) POWER	(AC) Power		Power
4	4	4	4
5	5	5	5
6	6	6	6
SLEEP	Sleep	SLEEP	Sleep / Timer
7	7	7	7
8	8	8	8
9	9	9	9
DISPLAY	Display	DISPLAY	Display / Media
10	10	0	0
+10	+10	GUIDE EPG	Guide / EPG / -/--
AUTO PRESET	Auto Preset	INFO	Info / Angle
INTRO	Intro	OK	OK
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Originalfernbedienung		Ersatzfernbedienung	
PROGRAM	Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
■/CLEAR	Stop	HOLD ■	Stop / Hold
■/CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
►/II	Play	SLOW ▶	Play / Slow
►/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
OPEN/ CLOSE	Open/Close	SURROUND ⏏	Eject / Surround
BAND	Tuner Band	PROGRAM TV/RADIO	TV/Radio /
STEREO AUTO/MONO	Stereo/Auto/mono	TITLE SOUND	Sound / Title
SEA DOWN	I<< Search	PRESET- ⏮	I<< / Preset-
SEA DOWN	Down	▼	Down
ARCH ►►I UP	Search >>I	PRESET+ ⏭	>>I / Preset+
ARCH ►►I UP	Up	▲	Up
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
TONE	Tone	FORMAT PICTURE	Picture / Format
VOLU	Vol -	VOL −	Vol -
LUME +	Vol +	VOL +	Vol +