Originalfernbedienung		Ersatzfernbedienung	
⏻/I	Standby/On	⏻	Power
MARK 1	1/Mark	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
10	10/←	GUIDE	Guide
≥10	+10/→	FAV PRE-CH	Pre Ch
DISP/CHARA	Disp/Chara	DISPLAY INFO	Info
CANCEL	Cancel	ZOOM ⏏	Eject
SET	Set	TOP MENU MENU	Menu
TITLE/EDIT	Title/Edit	RETURN BACK	Back

Originalfernbedienung		Ersatzfernbedienung	
ENTER	Enter	OK	Ok
GROUP SKIP ⏭	Group Skip >>I	⏭	>>I
I⏮	I<<Group Skip	⏮	I<<
⏭	>>I	»	>>
⏮	I<<	«	<<
PTY SEARCH ■	Stop/PTY	■	Stop
GROUP TITLE /EDIT	Group Title/Edi	HOME SMART	Smart
TITLE SEARCH	Title Search	PICTURE FORMAT	Format
CD ⏯	Play/Pause CD	PLAY MODE ▶	Play
MEMORY ⏯	Play/Pause	⏸	Pause
USB ⏯	Play/Pause USB	A	Red
iPod ⏯	Play/Pause iPo	D	Blue
AUX/ FM/AM	AUX/FM/AM	DISC NAV LIST	List
PLAY/ FM MODE	Play/FM Mode	SEARCH TV/R	TV/R
REPEAT TA/News/Info	Repeat/TA/News/I	REPEAT TEXT	Text
GROUP SELECT	Group Select	SETTINGS OPT	Options
A.STANDBY	A. Standby	CLEAR EXIT	Exit

Originalfernbedienung		Ersatzfernbedienung	
SLEEP	Sleep	PROG SLEEP	Sleep
CLOCK/ TIMER	Clock/Timer	TIMER AV	AV
DIMMER	Dimmer	ECO 3D	3D
HQ/ SP/EP	HQ/SP/EP	AD SUBT	Subt
REC SPEED	Rec Speed	REC MODE	Rec
MARKING MODE	Marking Mode	E-MANUAL D.MENU	D. Menu
SOUND MODE	Sound Mode	SOUND DUAL	Dual
AHB PRO	AHB PRO	B	Green
BASS/ TREBLE	Bass/Treble	C	Yellow
QP LINK USB MODE	QP Link/USB Mode	APP MEDIA	Media
+	Vol +	+ VOL	Vol +
− VOLUME	Vol -	VOL −	Vol -
FADE MUTING	Fade Muting	MUTE	Mute
	A1	SHIFT + 1	Shift + 1
	A2	SHIFT + 2	Shift + 2

Originalfernbedienung	Ersatzfernbedienung