Originalfernbedienung		Ersatzfernbedienung	
I/⏻	Power	⏻	Power
OPEN/CLOSE	Open/Close	ZOOM ⏏	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
ENTER	Enter	FAV PRE-CH	Pre Ch
TV/VIDEO TIME/TEXT	Time/Text	REPEAT TEXT	Text
PICTURE MODE	Picture Mode	PICTURE FORMAT	Format
AUDIO	Audio	SOUND DUAL	Dual

Originalfernbedienung		Ersatzfernbedienung	
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	A	Red
SUR	Sur	SETTINGS OPT	Options
SEARCH MODE	Search Mode	TIMER AV	AV
REPEAT	Repeat	SHIFT + REPEAT TEXT	Shift + Text
A-B	A-B	SHIFT + PLAY MODE ▶	Shift + Play
SHUFFLE	Shuffle	C	Yellow
SA-CD MULTI/2CH	SA-CD	HOME SMART	Smart
ALBUM +	Album+	+ CH	Ch +
ALBUM −	Album-	CH −	Ch -
ZOOM	Zoom	SHIFT + ZOOM ⏏	Shift + Eject
PICTURE NAVI	Picture Navi	SEARCH TV/R	TV/R
NEXT ▶▶I	>>I	▶▶I	>>I
PREV I◀◀	I<<	I◀◀	I<<
SCAN ▶▶ / SLOW	Scan >>/Slow	▶▶	>>
SCAN ◀◀	<< Scan/◁	◀◀	<<
INSTANT REPLAY ◀◀	←/Instant Replay/◁I Step	SHIFT + ◀◀	Shift + I<<

Originalfernbedienung	Ersatzfernbedienung
Step II >/ Instant Advance/ · →	SHIFT + >>I Shift + >>I
PLAY Play	PLAY MODE Play
PAUSE Pause	Pause
Up	Up
Down	Down
Right	Right
Left	Left
ENTER Enter	OK Ok
DISPLAY Display	DISPLAY INFO Info
MENU Menu	TOP MENU MENU Menu
TOP MENU Top Menu	SHIFT + TOP MENU MENU Shift + Menu
RETURN Return	RETURN BACK Back
STOP Stop	Stop
SA-CD/ CD SA-CD/CD	APP MEDIA Media

Originalfernbedienung	Ersatzfernbedienung

Originalfernbedienung		Ersatzfernbedienung	
I/⏻	Power	⏻	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
ENTER	Ent er	OK	Ok
TV/VIDEO TIME/TEXT	Tv/ Vi deo	SEARCH TV/R	TV/ R
VOL +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -

Originalfernbedienung	Ersatzfernbedienung