Originalfernbedienung		Ersatzfernbedienung	
STANDBY	Standby		Power
DTV/VCR	DTV/VCR	RDS AV INPUT	AV / Input / RDS
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
FAVORITE	Favorite	PC FAV MARKER	Fav / Marker / PC
INFO	Info	ANGLE INFO	Info / Angle
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
USB	USB	SHIFT + USB 8	Shift + 8
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SUB-T	Sub-T	EQ SUBTITLE	Subtitle / EQ
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Originalfernbedienung		Ersatzfernbedienung	
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI-SAT 0	0
GAME	Game	MEDIA DISPLAY	Display / Media
TEXT	Text	GOTO TEXT	Text / Goto
TV/RADIO	TV/Radio	PROGRAM TV/RADIO	TV/Radio /
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
PREV	Prev	PRESET-	I<< / Preset-
NEXT	Next	PRESET+	>>I / Preset+
REV	Rev	TUNE-	<< / Tune-
FWD	Fwd	TUNE+	>> / Tune+
MENU	Menu	HOME MENU	Menu / Home
CH+	Up / CH+		Up
CH+	Up / CH+	CH+ PAGE	CH+ / Page+
EXIT/RECALL	Exit/Recall	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
EXIT/RECALL Exit/Recall	RETURN BACK Back / Return		
VOL Left / Vol -	Left		
VOL Left / Vol -	VOL Vol -		
OK OK	OK OK		
VOL Right / Vol +	VOL Vol +		
VOL Right / Vol +	Right		
CH- Down / CH-	CH PAGE CH- / Page-		
CH- Down / CH-	Down		
Red	NETFLIX SEARCH Red / Netflix / Search		
Green	APP REPEAT Green / APP / Repeat		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		