Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Timer/Play	ANGLE INFO	Info / Angle
	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
	Sleep	TIMER SLEEP	Sleep / Timer
	Auto Off	SHIFT +	Shift + Power
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Originalfernbedienung		Ersatzfernbedienung	
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
≧10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
DEL	Del	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
PLAY MODE	Play Mode	SHIFT + SLOW ▶	Shift + Play /
DAB/FM	DAB/FM	NETFLIX SEARCH	Red / Netflix / Search
⏮/◀◀	<<|/ <<	TUNE- ◀◀	<< / Tune-
▶▶/⏭	>>|/ >>	TUNE+ ▶▶	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
CD▶/II	Play/Pause CD	SLOW ▶	Play / Slow
DISPLAY	Display	MEDIA DISPLAY	Display / Media
iPod▶/II	Play/Pause iPo	STEP - FREEZE II	Pause / Step / Freeze
RE-MASTER	Re-Master	FORMAT PICTURE	Picture / Format
SURROUND	Surround	SURROUND ⏏	Eject / Surround

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
D.BASS	D. Bass	LANG I/II AUDIO	Audio / Lang I/II		
▲	Up	▲	Up		
▼	Down	▼	Down		
iPod MENU	iPod Menu	HOME MENU	Menu / Home		
►	Right	►	Right		
PRESET EQ	Preset EQ	EQ SUBTITLE	Subtitle / EQ		
BASS/TREBLE	Bass/Treble	TITLE SOUND	Sound / Title		
◄	Left	◄	Left		
OK	OK	OK	OK		
DAB MENU	DAB Menu	TOP MENU D.MENU	D. Menu / Top		
AUTO PRESET	Auto Preset	LIST SMART	Smart / List		
TUNE MODE	Tune Mode	Prime Video RANDOM	Blue / Prime Video / Random		
DAB SECONDARY	DAB Secondary	YouTube REPEAT A-B	Yellow / YouTube / Repeat		