Mandis shop

WAVE MUSIC SYSTEM 1

Originalfernbedienung		Ersatzfernbedienung	
On/Off Stop Alarm	On/Off / Stop	Power	Power
Sleep	Sleep	TIMER SLEEP	Sleep / Timer
Mute	Mute	DIMMER MUTE	Mute / Dimmer
FM AM	FM/AM	SHIFT + TUNER 6	Shift + 6
FM AM	FM/AM	NETFLIX SEARCH	Red / Netflix / Search
CD	CD	APP REPEAT	Green / APP / Repeat
CD	CD	SHIFT + CD-STB 3	Shift + 3
AUX	AUX	YouTube REPEAT A-B	Yellow / YouTube / Repeat
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
Volume ▲	Vol +	VOL +	Vol +
1	Presets 1	TV 1	1
2	Presets 2	DVD 2	2
3	Presets 3	CD-STB 3	3
Volume ▼	Vol -	VOL −	Vol -
4	Presets 4	VIDEO 4	4
5	Presets 5	TAPE 5	5
6	Presets 6	TUNER 6	6

Originalfernbedienung		Ersatzfernbedienung	
Seek / ⏮	I<< Seek/Track	PRESET- ⏮	I<< / Preset-
Track ⏭	Seek/Track >>I	PRESET+ ⏭	>>I / Preset+
Play/Pause ▶II	Play	SLOW ▶	Play / Slow
Play/Pause ▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
Stop/Eject ⏏	Stop	HOLD ■	Stop / Hold
Stop/Eject ⏏	Eject	SURROUND ⏏	Eject / Surround
Tune/ <	< Tune/MP3	TUNE- ◀◀	<< / Tune-
/MP3 >	Tune/MP3 >	TUNE+ ▶▶	>> / Tune+
Time −	Time-	CH PAGE −	CH- / Page-
Time +	Time+	CH PAGE +	CH+ / Page+
Play Mode	Play Mode	LIST SMART	Smart / List
Alarm On/Off	Alarm On/Off	OK	OK
Alarm Wake To	Alarm Wake To	▶	Right
Alarm Time Menu	Alarm	◀	Left
Alarm Time Menu	Alarm	HOME MENU	Menu / Home