Mandis shop

GX-IR05

Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
START	Start	SLOW	Play / Slow
Stop	Stop	HOLD	Stop / Hold
10SEC	10 Sec	SIZE ZOOM	Zoom / Size
Clock	Clock	TIMER SLEEP	Sleep / Timer
EDIT	Edit	OPT-TOOLS SETUP	Setup / OPT /
UP	Up		Up
Stopwatch	Stopwatch	Prime Video RANDOM	Blue / Prime Video / Random
	Left		Left
Enter	Enter	OK	OK
	Right		Right
HIIT EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Down	Down		Down
FGB2 RESET	Reset	RETURN BACK	Back / Return
TABATA Cycle	Cycle Tabata	+ VOL	Vol +
F-A	F-A	LIST SMART	Smart / List

Originalfernbedienung		Ersatzfernbedienung	
FGB1 Timer	Timer Up/FGB1	+ CH PAGE	CH+ / Page+
Alarm HIIT	Alarm HIIT	VOL −	Vol -
C-U	C-U	MEDIA DISPLAY	Display / Media
Timer FGB2	Timer	CH PAGE −	CH- / Page-
1 P1	1/P1	TV 1	1
2 P2	2/P2	DVD 2	2
3 P3	3/P3	CD-STB 3	3
4 P4	4/P4	VIDEO 4	4
5 P5	5/P5	TAPE 5	5
6 P6	6/P6	TUNER 6	6
7 P7	7/P7	AUX-HDD 7	7
8 P8	8/P8	USB 8	8
9 P9	9/P9	BLUETOOTH 9	9
WRC	WRC	-/-- GUIDE EPG	Guide / EPG / -/--
0 P0	0/P0	HDMI-SAT 0	0
A+ 12/24H	A+/12/24H	PC FAV MARKER	Fav / Marker / PC

https://remotecontrols.de/Fitness-Tech/10653-9791-ersatzfernbedienung-fur-Fitness-Tech-GX-IR05.htm