Originalfernbedienung	Ersatzfernbedienung
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Source	AV / Input / RDS
0	0
·	Shift + Guide / EPG / -/--
☼	Setup / OPT /
Up	Up
Exit	Exit / Cancel / Clear

Originalfernbedienung	Ersatzfernbedienung
Left	Left
OK	OK
Right	Right
Down	Down
Back	Back / Return
Menu	D.Menu / Top
Netflix	Shift + Red / Netflix /
YouTube	Shift + Yellow / YouTube /
prime video	Shift + Blue / Prime
Google Play	Shift + Green / APP /
Vol +	Vol +
Grid	Smart / List
P+	CH+ / Page+
Vol -	Vol -
Home	Menu / Home
P-	CH- / Page-
Info	Info / Angle

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
USB	USB	SHIFT + USB 8	Shift + 8		
MTS	MTS	MEDIA DISPLAY	Display / Media		
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
■	Stop	HOLD ■	Stop / Hold		
●	Rec	REC MODE ●	Rec / Rec Mode		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
❙◀◀	I <<	PRESET- ❙◀◀	I << / Preset-		
▶▶❙	>>I	PRESET+ ▶▶❙	>>I / Preset+		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
●	Red	NETFLIX SEARCH	Red / Netflix / Search		
●	Green	APP REPEAT	Green / APP / Repeat		
●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
●	Blue	Prime Video RANDOM	Blue / Prime Video / Random		