Mandis shop

LG AKB36086232

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
PRESET/FOLDER	Preset/Folder+	CH PAGE	CH- / Page-
PRESET/FOLDER	Preset/Folder+	SHIFT +	PRESET+ Shift + >>I / Preset+
FUNCTION	Function	HOME MENU	Menu / Home
VOLUME	Volume+	VOL +	Vol +
	Preset/Folder-	CH PAGE +	CH+ / Page+
	Preset/Folder-	SHIFT +	PRESET- Shift + I<< / Preset-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Volume-	VOL –	Vol -
REPEAT /RANDOM	Repeat /	APP REPEAT	Green / APP / Repeat
REPEAT /RANDOM	Repeat /	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT /RANDOM	Repeat /		Up
INFO	Info	ANGLE INFO	Info / Angle
TUN.–	<< / I<< / Tun	PRESET-	I<< / Preset-
TUN.–	<< / I<< / Tun	TUNE-	<< / Tune-
TUN.–	<< / I<< / Tun		Left

Originalfernbedienung		Ersatzfernbedienung	
	Stop	OK	OK
	Stop	HOLD	Stop / Hold
TUN.+	>> / >>I /	PRESET+	>>I / Preset+
TUN.+	>> / >>I /	TUNE+	>> / Tune+
TUN.+	>> / >>I /		Right
PROGRAM /MEMO	Program/Memo	PC FAV MARKER	Fav / Marker / PC
PROGRAM /MEMO	Program/Memo	PROGRAM TV/ RADIO	TV/Radio /
▶/II	Play / Pause	SLOW	Play / Slow
▶/II	Play / Pause		Down
▶/II	Play / Pause	STEP-FREEZE	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
RDS	RDS	MEDIA DISPLAY	Display / Media
PTY	PTY	LIST SMART	Smart / List

https://remotecontrols.de/LG/10696780-ersatzfernbedienung-fur-LG-AKB36086232.htm