Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat
A-B	A-B	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
N/P	N / P	TOP MENU / D.MENU	D. Menu / Top
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SUBTITLE	Subtitle	EQ / SUBTITLE	Subtitle / EQ
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
ANGLE	Angle	ANGLE / INFO	Info / Angle
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LANGUAGE	Language	LANG I/II / AUDIO	Audio / Lang I/II

Originalfernbedienung		Ersatzfernbedienung	
0	0	HDMI - SAT 0	0
10+	10+	-/-- / GUIDE EPG	Guide / EPG / -/--
TIME	Time	TIMER / SLEEP	Sleep / Timer
SETUP	Setup	OPT-TOOLS / SETUP	Setup / OPT /
	Up		Up
TITLE	Title	TITLE / SOUND	Sound / Title
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
PBC	PBC	FORMAT / PICTURE	Picture / Format
	Down		Down
MENU	Menu	HOME / MENU	Menu / Home
VOL-	Vol -	VOL -	Vol -
ZOOM	Zoom	SIZE / ZOOM	Zoom / Size
VOL+	Vol +	+ VOL	Vol +
RETURN	Return	RETURN / BACK	Back / Return
L/R	L / R	GOTO / TEXT	Text / Goto

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
STEP	Step	SHIFT + STEP-FREEZE	Shift + Pause / Step /		
SLOW	Slow	SHIFT + SLOW	Shift + Play /		
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
PREV	Prev I<<	PRESET-	I<< / Preset-		
NEXT	Next >>I	PRESET+	>>I / Preset+		
REV	Rev <<	TUNE-	<< / Tune-		
FWD	Fwd >>	TUNE+	>> / Tune+		
V-MODE	V-Mode	LIST SMART	Smart / List		
STOP	Stop	HOLD	Stop / Hold		
PLAY/PAUSE	Play / Pause	SLOW	Play / Slow		
PLAY/PAUSE	Play / Pause	STEP-FREEZE	Pause / Step / Freeze		