Originalfernbedienung		Ersatzfernbedienung	
RECEIVER AMP	Power Receiver		Power
DISPLAY	Display	DISPLAY INFO	Info
BD/DVD	BD / DVD	1	1
VCR/DVR	VCR / DVR	2	2
CBL/SAT	CBL / SAT	3	3
GAME	GAME	4	4
PC	PC	5	5
AUX	AUX	6	6
TUNER	TUNER	TIMER AV	AV
TUNER	TUNER	7	7
TV/CD	TV / CD	8	8
PHONO	PHONO	9	9
PORT	PORT	GUIDE	Guide
NET	NET	SHIFT + APP MEDIA	Shift + Media
NET	NET	0	0
USB	USB	APP MEDIA	Media
USB	USB	FAV PRE-CH	Pre Ch

Originalfernbedienung		Ersatzfernbedienung	
MUTING	Muting	MUTE	Mute
VOL	Vol +	VOL +	Vol +
VOL	Vol -	VOL −	Vol -
HOME	Home	HOME SMART	Smart
CH DISC	CH+	CH +	Ch +
ALBUM	CH-	CH −	Ch -
GUIDE/TOP MENU SP LAYOUT	SP Layout	E-MANUAL D.MENU	D. Menu
PREV CH/MENU VIDEO	Menu	TOP MENU MENU	Menu
	Up		Up
PLAYLIST	Left		Left
ENTER	Enter	OK	Ok
PLAYLIST	Right		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	I <<		I <<
	>>I		>>I

Originalfernbedienung		Ersatzfernbedienung	
	<<		<<
	Play		Play
	>>		>>
	Pause / Play Rev		Pause
	Stop		Stop
	Movie / TV		Red
	Music		Green
	Game		Yellow
	Thx		Blue
	Dimmer		Dual
	D. TUN		TV/R
	Sleep		Sleep
	1		Shift + 1
	2		Shift + 2
	3		Shift + 3
	4		Shift + 4
	5		Shift + 5

Originalfernbedienung		Ersatzfernbedienung	
	6		Shift + 6
	7		Shift + 7
	8		Shift + 8
	9		Shift + 9
	0		Shift + 0

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER AMP	Power Receiver		Power
BD/DVD	BD / DVD	1	1
VCR/DVR	VCR / DVR	2	2
CBL/SAT	CBL / SAT	3	3
GAME	GAME	4	4
PC	PC	5	5
AUX	AUX	6	6
TUNER	TUNER	TIMER AV	AV
TUNER	TUNER	7	7
TV/CD	TV / CD	8	8
PHONO	PHONO	9	9
PORT	PORT	GUIDE	Guide
NET	NET	SHIFT + APP MEDIA	Shift + Media
NET	NET	0	0
USB	USB	APP MEDIA	Media
USB	USB	FAV PRE-CH	Pre Ch
MUTING	Muting	MUTE	Mute

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL –	Vol -
HOME	Home	HOME SMART	Smart
CH DISC	CH+ / Album+	+ CH	Ch +
ALBUM	CH- / Album-	CH –	Ch -
GUIDE/TOP MENU SP LAYOUT	Top Menu	E-MANUAL D.MENU	D. Menu
PREV CH/MENU VIDEO	Menu	TOP MENU MENU	Menu
	Up		Up
PLAYLIST	Page- / Playlis		Left
ENTER	Enter	OK	Ok
PLAYLIST	Page+ / Playlist		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	I <<		I <<
	>>I		>>I
	<<		<<

Originalfernbedienung		Ersatzfernbedienung	
	Play	PLAY MODE	Play
	>>	>>	>>
	Pause	II	Pause
	Stop	■	Stop
SEARCH MOVIE/TV	Search	SEARCH TV/R	TV/R
SEARCH MOVIE/TV	Search	A	Red
REPEAT MUSIC	Repeat	B	Green
REPEAT MUSIC	Repeat	REPEAT TEXT	Text
RANDOM GAME	Random	C	Yellow
MODE THX	Mode	D	Blue
MODE THX	Mode	SHIFT + PLAY MODE	Shift + Play
1	1	SHIFT + 1	Shift + 1
2	2	SHIFT + 2	Shift + 2
3	3	SHIFT + 3	Shift + 3
4	4	SHIFT + 4	Shift + 4
5	5	SHIFT + 5	Shift + 5
6	6	SHIFT + 6	Shift + 6

Originalfernbedienung		Ersatzfernbedienung	
7	7	SHIFT + 7	Shift + 7
8	8	SHIFT + 8	Shift + 8
9	9	SHIFT + 9	Shift + 9
11 0	0	SHIFT + 0	Shift + 0
--/--- 10 +10 D.TUN DIMMER	--/--- +10	SHIFT + -/-- GUIDE	Shift + Guide
12 CLR SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
12 CLR SLEEP	CLR	CLEAR EXIT	Exit

Originalfernbedienung	Ersatzfernbedienung
Power Receiver	Power
Display	Info
BD / DVD	1
VCR / DVR	2
CBL / SAT	3
GAME	4
PC	5
AUX	6
TUNER	7
TV / CD	8
PHONO	9
TUNER	AV
PORT	Guide
NET	0
NET	Shift + Media
USB	Pre Ch
USB	Media

Originalfernbedienung	Ersatzfernbedienung
Muting	Mute
Vol +	Vol +
Vol -	Vol -
Home	Smart
CH+	Ch +
CH-	Ch -
SP Layout	Shift + Menu
Menu	Menu
Up	Up
Left	Left
Enter	Ok
Right	Right
Down	Down
Setup	Options
Return	Back
I <<	I <<
>>I	>>I

Originalfernbedienung		Ersatzfernbedienung	
	<<		<<
	>>		>>
	Play		Play
	Pause		Pause
	Stop		Stop
	Movie / TV		Red
	Music		Green
	Game		Yellow
	Thx		Blue
	Dimmer		Dual
	D. TUN		TV/R
	Sleep		Sleep
	1	SHIFT + 1	Shift + 1
	2	SHIFT + 2	Shift + 2
	3	SHIFT + 3	Shift + 3
	4	SHIFT + 4	Shift + 4
	5	SHIFT + 5	Shift + 5

Originalfernbedienung		Ersatzfernbedienung	
	6	SHIFT + 6	Shift + 6
	7	SHIFT + 7	Shift + 7
	8	SHIFT + 8	Shift + 8
	9	SHIFT + 9	Shift + 9
	0	SHIFT + 0	Shift + 0

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER AMP	Power		Power
DISPLAY	Display	DISPLAY INFO	Info
BD/DVD	BD / DVD	1	1
VCR/DVR	VCR / DVR	2	2
CBL/SAT	CBL / SAT	3	3
GAME	GAME	4	4
PC	PC	5	5
AUX	AUX	6	6
TUNER	TUNER	7	7
TUNER	TUNER	TIMER AV	AV
TV/CD	TV / CD	8	8
PHONO	PHONO	9	9
PORT	PORT	-/-- GUIDE	Guide
NET	NET	0	0
NET	NET	SHIFT + APP MEDIA	Shift + Media
USB	USB	FAV PRE-CH	Pre Ch
USB	USB	APP MEDIA	Media

Originalfernbedienung		Ersatzfernbedienung	
MUTING	Muting	MUTE	Mute
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL –	Vol -
HOME	Home	HOME SMART	Smart
CH DISC	CH+	+ CH	Ch +
ALBUM	CH-	CH –	Ch -
GUIDE/TOP MENU SP LAYOUT	SP Layout	SHIFT + TOP MENU MENU	Shift + Menu
PREV CH/MENU VIDEO	Menu	TOP MENU MENU	Menu
	Up		Up
PLAYLIST	Left		Left
ENTER	Enter	OK	Ok
PLAYLIST	Right		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	I<<		I<<
	>>I		>>I

Originalfernbedienung		Ersatzfernbedienung	
	<<		<<
	>>		>>
	Play		Play
	Pause		Pause
	Stop		Stop
	Movie / TV		Red
	Music		Green
	Game		Yellow
	Thx		Blue
	Dimmer		Dual
	D. TUN		TV/R
	Sleep		Sleep
	1	SHIFT + 1	Shift + 1
	2	SHIFT + 2	Shift + 2
	3	SHIFT + 3	Shift + 3
	4	SHIFT + 4	Shift + 4
	5	SHIFT + 5	Shift + 5

Originalfernbedienung		Ersatzfernbedienung	
	6	SHIFT + 6	Shift + 6
	7	SHIFT + 7	Shift + 7
	8	SHIFT + 8	Shift + 8
	9	SHIFT + 9	Shift + 9
	0	SHIFT + 0	Shift + 0