Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Open/Close	SURROUND	Eject / Surround
FUNCTION TV/SOURCE	Function	RDS AV INPUT	AV / Input / RDS
RDS DISPLAY 1	1/RDS Display	TV 1	1
2	2	DVD 2	2
TA 3	3/TA	CD-STB 3	3
PTY- 4	4/PTY-	VIDEO 4	4
PTY SEARCH 5	5/PTY Search	TAPE 5	5
PTY+ 6	6/PTY+	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
0	0	HDMI-SAT 0	0
TITLE MENU POPUP	Title Menu PopUp	SHIFT + TOP MENU D.MENU	Shift + D.Menu / Top Menu
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+

Originalfernbedienung		Ersatzfernbedienung	
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
VOL	Vol +	VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING /CH	Tuning/CH-	CH PAGE	CH- / Page-
TUNING /CH	Tuning/CH+	CH PAGE	CH+ / Page+
VOL	Vol -	VOL	Vol -
TV SOUND	Tv Sound	TITLE SOUND	Sound / Title
S/W LEVEL	S/W Level	FORMAT PICTURE	Picture / Format
HOME	Home	HOME MENU	Menu / Home
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	Left		Left		
	Enter	OK	OK		
	Right		Right		
RETURN	Return	RETURN BACK	Back / Return		
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
A	Red	NETFLIX SEARCH	Red / Netflix / Search		
B	Green	APP REPEAT	Green / APP / Repeat		
TUNER MEMORY C	Yellow/Tuner	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
MO/ST D	Blue/Mo/St	Prime Video RANDOM	Blue / Prime Video / Random		
SMART HUB	Smart Hub	LIST SMART	Smart / List		
SEARCH	Search	SHIFT +	NETFLIX SEARCH Shift + Red / Netflix /		
SOUND EFFECT	Sound Effect	SHIFT +	TITLE SOUND Shift + Sound / Title		
3D SOUND	3D/Sound	LANG I/II AUDIO	Audio / Lang I/II		

Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Function		AV / Input / RDS
	1/ RDS Display		1
	2		2
	3/ TA		3
	4/ PTY-		4
	5/ PTY Search		5
	6/ PTY+		6
	7		7
	8		8
	9		9
	0		0
	I <<		I << / Preset-
	>>I		>>I / Preset+
	<<		<< / Tune-
	>>		>> / Tune+
	Stop		Stop / Hold

Originalfernbedienung		Ersatzfernbedienung	
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Vol +		Vol +
	Mute		Mute / Dimmer
	Tuning/ CH-		CH- / Page-
	Tuning/ CH+		CH+ / Page+
	Vol -		Vol -
	Tv Sound		Sound / Title
	Home		Menu / Home
	Sleep		Sleep / Timer
	Tools		Setup / OPT /
	Up		Up
	Info		Info / Angle
	Left		Left
	Enter		OK
	Right		Right
	Return		Back / Return

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
A	Red	NETFLIX SEARCH	Red / Netflix / Search		
B	Green	APP REPEAT	Green / APP / Repeat		
TUNER MEMORY C	Yellow/Tuner	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
MO/ST D	Blue/Mo/St	Prime Video RANDOM	Blue / Prime Video / Random		
SMART HUB	Smart Hub	LIST SMART	Smart / List		
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		