Mandis shop

Samsung BN5901259B

Original	Replacement	Original	Replacement
Power	Power	Source	SRC
OK	OK	TTX/MIX	TEXT
Up	UP	1	1
Down	DOWN	2	2
Right	RIGHT	3	3
Left	LEFT	4	4
Return	BACK	5	5
Play	Play	6	6
Pause	Pause	7	7
Extra	MEDIA	8	8
Mute	MUTE	9	9
Vol+	VOL +	0	0
Vol-	VOL -	PRE-CH	P/C / FAV
Guide	-/-- / EPG	Exit	EXIT
CH+	CH +	Info	INFO
CH-	CH -	Menu	MENU
Home	VOD	Red	Red (A)

https://remotecontrols.dk/en/Samsung/1034581-78618-replacement-remote-control-for-Samsung-TM1850A-BN59-01259B.html

Original	Replacement	Original	Replacement
Green	Green (B)		
Yellow	Yellow (C)		
Blue	Blue (D)		
123	TV/R		
Tools	OPT+		
Stop	Stop		
Rec	Rec		
<<|<<	Rewind		
>>/>>|	Fast Forward		
CH List	WIDE		
AD/Subt.	Subt.		
E-Manual	Audio		