Original		Replacement	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
TXT	TXT	GOTO TEXT	Text / Goto
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original		Replacement	
CEC	CEC	LIST SMART	Smart / List
?	?	TOP MENU D.MENU	D. Menu / Top
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
BACK	Back	RETURN BACK	Back / Return
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
+	Vol +	+ VOL	Vol +
	Source	RDS AV INPUT	AV / Input / RDS
+ P	PR+	+ CH PAGE	CH+ / Page+
−	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement		Original	Replacement
P –	PR-	CH PAGE –	CH- / Page-		
⏮	I <	PRESET- ⏮	I << / Preset-		
⏭	>I	PRESET+ ⏭	>>I / Preset+		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
●	Rec	REC MODE ●	Rec / Rec Mode		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
■	Stop	HOLD ■	Stop / Hold		
[<>]	[<>]	FORMAT PICTURE	Picture / Format		
	Dialog	LANG I/II AUDIO	Audio / Lang I/II		
	[...]	EQ SUBTITLE	Subtitle / EQ		
TV/Radio	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /		
My Media	My Media	MEDIA DISPLAY	Display / Media		