Original		Replacement	
	Power		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	<<		<< / Tune-
	>>		>> / Tune+
LANG.	Lang		Audio / Lang I/II
	Source (Games)		Eject / Surround
	Movie-Music-Phot		Picture / Format
	[≡]. .		Zoom / Size
	*/O		Sleep / Timer
	TV		TV/Radio /
Q. MENU	Q. Menu		D. Menu / Top
	[-O-]		Setup / OPT /
	[≡]/Text		Text / Goto

Original		Replacement	
MENU	Menu		Menu / Home
	Up		Up
i	i		Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
EXIT	Exit		Exit / Cancel / Clear
	Down		Down
BACK	Back		Back / Return
V	Vol +	VOL	Vol +
	World (Violet)	SMART	Smart / List
P	PR+	CH PAGE	CH+ / Page+
V	Vol -	VOL	Vol -
*/Q			Display / Media
P	PR-	CH PAGE	CH- / Page-
1	1	1	1
2	2	2	2

Original		Replacement		Original	Replacement
3 def	3	CD - STB 3	3		
4 ghi	4	VIDEO 4	4		
5 jkl	5	TAPE 5	5		
6 mno	6	TUNER 6	6		
7 pqrs	7	AUX - HDD 7	7		
8 tuv	8	USB 8	8		
9 wxyz	9	BLUETOOTH 9	9		
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
	Recall	SHIFT + RETURN BACK	Shift + Back / Return		